



## How To Measure:

### Inside Mount

1. Measure the width of the inside of the window frame at the top, middle, and bottom. Record the narrowest measurement.
2. Lotus Horizontal Blinds have 1/2" deduction for Inside Mount. Select a size width that matches your measurement in step 1. The blind can be up to to 3/4" smaller than measurement. For best fit, find the size with a width closest to your measurement.
3. Measure the height at the left and right of the inside of the window frame. Record the longest measurement. A blind longer than your required length will work as the blind can be stopped at any position.

### Outside Mount

1. Measure the width of the outside of the window frame at the top, middle, and bottom. Record the widest measurement.
2. Lotus & Windoware Horizontal Blinds have 1/2" deduction for Inside Mount. For Outside Mount, add a minimum of 1/2" to the width measurement.
3. Measure the height at the left and right of the outside of the window frame to the top of the window frame. Record the longest measurement. A blind longer than your required length will work as the blind can be stopped at any position.